



Glass Handrail Bracket Installation Instructions

Before You Begin

Make sure your glass pieces already have the holes drilled and you have all components handy.

Tools You'll Need

#4 Allen Wrench
#2.5 Allen Wrench

Step-By-Step Instructions

1. Insert the threaded rod into the locking disk. Make sure the allen wrench side of the rod is facing away from the locking disk.
2. Insert a #4 allen wrench into the threaded rod and tighten. Then slide one of the nylon washers over the threaded rod and onto the disk.
3. Insert the second nylon washer into the hole on the side of the glass where you will mount the handrail.
4. While holding the locking disk in the hole on the backside of the glass, insert the disk side of your handrail bracket into the nylon washer on the front side of your glass. Screw the locking disk on the back of the glass and the handrail bracket on the front of the glass together until the nylon washers meet up on the inside of the glass panel. This will cushion your glass from touching any metal.
5. Orient your handrail bracket to the desired angle. Then, insert the #2.5 allen wrench into the small hole at the top of the locking disk on the backside of the glass. Use the allen wrench as a lever (do not twist) to tighten the pieces together completely. This will lock the entire bracket into place.